

Joint sizes for FR Robot models

| | FR3 | FR5 | FR10 | FR16 | FR20 | FR30 |
|---------|-----|-----|------|------|------|------|
| Joint 1 | 17 | 25 | 32 | 32 | 40 | 40 |
| Joint 2 | 17 | 25 | 32 | 32 | 40 | 40 |
| Joint 3 | 17 | 25 | 25 | 25 | 32 | 32 |
| Joint 4 | 14 | 14 | 17 | 17 | 25 | 25 |
| Joint 5 | 14 | 14 | 17 | 17 | 25 | 25 |
| Joint 6 | 14 | 14 | 17 | 17 | 25 | 25 |